


INSTRUCTIONS FOR USING DVD/VCR PLAYER WITH SYMPODIUM UNIT

Turning on the Sympodium and DVD/VCR System – (Requires approx. 5 min.)

1. Plug in the cream-colored computer power cord into electrical outlet.
2. Select the input source number 2 (see the illustration on the right).
3. Turn on the projector by pressing the power button on its top.
4. Open the left cabinet door to access VCR/DVD combo player
5. Turn on the players' power button. (A red light will come on).
6. Select the output button to choose between DVD and VCR. (A green light will show which mode is selected).



STEP 1

Using the DVD/VCR Combo Player

VCR	DVD
Put VHS tape into slot on left of player.	Press the open/close button to open the DVD tray
Press the Play button	Put the DVD disk in the tray
Use the Fast Forward, Rewind; stop/eject buttons if necessary.	Press the Close button
Once finished – press stop button 2 times to eject the tape	Press Play

Note: The DVD/VCR remote controller is on the top of the player and is available for use.

STEP 2

Turning off the Sympodium and DVD/VCR System (Requires approx. 5 min.)

1. Turn off the projector by pressing the power button on its top.
2. Eject your VHS tape or DVD
3. Press the DVD/VCR player's power button – the red light will go off.
4. Close the cabinet.
5. **Important:** Wait for the projector fan to stop running.
6. Then unplug the cream-colored power cord.

STEP 3